



C351 BOAT

Plastic 2000mm
Quicklink: Q6E2D

General

Colour	White
Construction	Plastic - Purotouch

Dimensions

Height	74mm
Length	2m
Width	173mm

A cornice creates a visually attractive transition from wall to ceiling. From sleek to baroque, from decorative to functional – we offer a quality solution for every budget. The profiles are easy to install, and a large number of designs are available.

Cleanly curved, generous profile which creates a lovely interplay of light and shadow. Use our indirect lighting profiles to provide your space with an instant upgrade. Designed by Jacques Vergracht. Installation remark: It is necessary to screw this profile on the wall.

It gently slopes upwards to create a wonderful lighting effect on both the wall and ceiling. Perfect for larger sized rooms or for properties with tall ceilings. Uplighting or trough style cornice is becoming more and more popular for use in restaurants, bars and hotels due to its simple & contemporary look.

These covings conceal LED indirect light and allow the creation of subtle lighting effects. All covings will bring warmth to a room, and take away the harshness of a single central pendant light fitting. Compact LEDs are easy to install, cost little to run and have a long life whilst being environmentally friendly.

LEDs come in a variety of colour temperatures from warm white to cool white also RGBW for a full range of colour choices.

All Cornice Moulding Extrusions are lightweight and can be installed using strong glue - see below for details and download the installation guide for further information.

1. Install Cornice Moulding Extrusion using DecoFix Hydro Adhesive FDP700, no need for screws or pins.
2. One tube of DecoFix Hydro Adhesive FDP700 will fit between 3-4 two metre lengths of each extrusion.
3. Best practice on cleaning off overspill along lengths is to leave the glue in place until the following day, then with a Stanley Blade cut a small piece and simply peel off all exposed residue.
4. Failure to use DecoFix Extra Adhesive FX210 as a joint adhesive will result in shrinkage, and light coming through joints.
5. Use DecoFix Extra Adhesive FX210 on all butt and mitre joints.



6. Leaving excess DecoFix Extra Adhesive FX210 for an hour before wiping of the overspill (removal before that time may result in gaps with light shining through on joints).
7. Remove the overspill with a decorators trowel or spatula. Then wipe back with acetone or Industrial wipes.
8. Do not use fingers as the glue can leave a black stain on skin.

All products have a matte primed surface, they are ready to paint. We advise to use water-based paint, and in case another type of finishing is used, we recommend prior testing. We are not responsible for the result after manipulation.

