

Installation Instruction

GIROFIX


Recessed Downlight

Art.

5085

5086


5226



Lamp Not Included

CAUTIONS

1. Switch-off the power supply before any installation and maintenance operations.




2. Installation should be carried out by a suitably qualified person in accordance with good electrical practice and the appropriate national wiring regulations.
3. Use this light fixture at the rated voltage and frequency as indicated on the specification table.

INSTALLATION

1


Make a hole at false ceiling.

ART.	Hole (mm)
5085	Ø 52
5086	Ø 69
5226	Ø 69




2

ART. 5085




ART. 5086
5226




3


ART. 5085



ART. 5086





ART. 5216





4

ART. 5085

ART. 5086
5226

MEASUREMENT

ART. 5085

ART. 5086
5226

SPECIFICATION

ART.	Max. Wattage(W)	Volt.(V)	Lamp	Remarks
5085	35	12	GU4 MR11	*
	4	12	GU4 MR11 LED	*
5086	50	12	GU5.3 MR16	*
5226	50	230/50	GU10/GZ10	N.A.

*Remote transformer required