

# Display Units

Wise Box Table Top Display Unit - Wise Box Receiver, Intense Switch & Remote  
4 Channel, 10 Amps / Circuit



## WISE DISPLAY 4

4 Channel, 10 Amps / Circuit  
Quicklink: Q4084

### General

Construction Aluminium / Plastic

Detection Range 200m

### Dimensions

Depth 175mm

Height 350mm

Width 320mm

### Electrical

Amperage 20A

Maximum Amps /  
Circuit 10A

Minimum Wattage  
per Circuit 1W

Voltage 240V

The Wise Box Table Top Display designed with wholesalers in mind, its the perfect solution for showcasing the features of the Wise Controls wireless lighting to any customer.

The **Wise Box Version 2 Kit** is an updated version of the original Wise Box Kit. Version 2 features four PIR timer dials for each circuit, allowing up to 16 PIR's to be connected.

The Version 2 kit also includes a 4 button Ilike keyfob and a 4 button Intense wall switch.

The Wisebox unit will control your lights, water features, electric shutters and gates etc. Once programmed, place the indoor wireless switch in a suitable location and the installation is complete. Enjoy switching your circuits from anywhere in your garden or home with the remote control.

The WiseBox Kit has a receiver that has four 10 amp circuits with a maximum amperage of 20 amps. The WiseBox kit has a 200 metre range. These circuits can be changed from switching to an open circuit. Each circuit on the WiseBox is fused individually with a 10 amp fuse to protect all the circuits.

### Programming Options

#### Option 1

##### **Single Button On and Off**

Programming this way will create an on and off from a single button on a wireless switch / remote.

#### Option 2

##### **Dual button On and Off**

Programming this way will assign your On and Off to 2 separate buttons.

#### Option 3

##### **PIR / Timelag function**

Programming this way only sends an ON signal, which is then switched off by a pre-set countdown timer. If you program to a PIR, then the PIR will reset itself to the pre-set time every time the sensor is triggered. If programmed to a switch or remote, then the countdown will switch off when it reaches 0 seconds.

### Wise Switches / Remotes

The keyfob and the wall switch included within the kit both have four buttons. Once you

# Display Units

Wise Box Table Top Display Unit - Wise Box Receiver, Intense Switch & Remote  
4 Channel, 10 Amps / Circuit

---

have programmed the button of your choice to link with a channel, that button will switch the channels circuit on / off. You can add additional switches and remotes to a WiseBox if you wish, up to a maximum of 16.

## Wise Controls Introduction Video

