Prism Flat Plate Clear Perspex

Prism Speaker Socket

1 gang speaker socket Clear Perspex



MRCPSP1

1 gang speaker socket Clear Perspex Quicklink: Q164A

General

Colour Clear

Construction Clear Perspex

Dimensions

Plate Depth 2mm

Electrical

Voltage 240V



Make your light switches almost disappear with our clear faceplate Prism. This is a high quality accessory that sits discreetly in an interior. Produced with square corners, it features high-quality inserts for exceptional product reliability. To ensure design uniformity throughout a project, non-standard accessories can be made to suit requirements.

- Acrylic thermoplastic flat faceplate
- Bevelled and flame polished edge
- Secondary fix
- Supplied with a template for fitting
- Ambassador style trimmed rocker switches are supplied as standard
- Pan head slotted screws
- Rotary dimmer, toggle and push button grid switches feature screwless plates as standard