

The RS / SP Driver Safety Cover is used to protect the user against the bare terminals of the RS / SP range of DC transformers.

The cover is attached using 2 clips which fixes it to the holes on the top of the driver.

We strongly recommend that you use either the Safety Cover or the Enclosures in order to protect yourself from electric shocks, and to protect the driver against dust.



RS SAFETY COVER

General	
Construction	Plastic
Dimmable	No
Dimensions	
Length	95mm
Width	50mm